



Theofilly and Billy Ginis

5/39 Tannadice St

Winnellie NT 0820

Contact Phone: 0488 325 552 – 0419 258 424

alawacm@live.com.au



Find us on Facebook: www.facebook.com/alawacabinetmakers
or visit our website at: www.alawacabinetmakers.com.au

ABN: 13 385 374 566

Alawa Cabinetmakers Bathroom Renovation Steps and Procedures:

1. Acceptance of quote with choice of cabinetry/tiles/accessories:
 1. Colours for doors, drawers, and panels.
 2. Benchtop style and colour (20mm stone or 32mm laminated benchtops).
 3. Choice of hardware (Soft-closing doors and drawers, with standard handles).
 4. Choice of tiles.
 5. Choice of tapware, toilet, basin, shower screen, ect. (If being organised and supplied by Alawa Cabinetmakers will be standard and selected by us.)
2. Supply of 3D bathroom drawing to client to see realistic view of job (if required).
3. Deposit payment to secure job.
4. Acceptance of 3D drawing and any final changes to be made. (Please note, if alterations change the price already invoiced, the extra will be invoiced separately, and paid immediately.
5. Please purchase your hardware and drop them off at the workshop. (For staff to be able to use appliance specifics for drawings). Required appliances are stated below:
 - * Basin and taps.
6. Vanity will be made in workshop.
7. Demolition of bathroom in order off:
 1. Please make sure bathroom area is prepped by removing all objects from inside cabinets being removed and covering anything within the working area and any other areas affected by the renovation in case of any dust or mess.
 2. Electrician: Disconnection of all current electronic appliances.
 3. Plumber: Disconnection of basin, toilet, ect.
 4. Removal and disposal of quoted bathroom works.
8. All plumbing and electrical changes will then be made.
9. Tiling works. (Please make sure if there is any tiling or floor work required that this be organised and communicated between all parties involved; and that all required preparation works are completed before installation of new cabinets. If only splashback is required, this will be done after the installation of the vanity top).
10. Installation of vanity and other agreed upon works.
11. Benchtops:
 - a) If 32mm laminated benchtops, they will be measured and made in workshop for installation in 2 to 3 business days. (Please note, there may be delay due to wet weather which may prevent the tops from being created.)
 - b) If 20 mm stone, measurements will be taken by stone mason after installation of vanity, and benchtop will be made at their workshop and installed in 5 to 7 business days depending on availability; a definite time will be scheduled at or after measurements are taken. (Please note hardware will need to be made



Theofilly and Billy Ginis

5/39 Tannadice St

Winnellie NT 0820

Contact Phone: 0488 325 552 – 0419 258 424

alawacm@live.com.au



Find us on Facebook: www.facebook.com/alawacabinetmakers

or visit our website at: www.alawacabinetmakers.com.au

ABN: 13 385 374 566

available to stone mason when measuring up for tops. These include the basin and tap.)

12. Electrician and plumber return to re-install hardware.
13. Any painting, cornicing, skirting or other fix ups required. (Please note, you will almost always require touch-ups to be made after completion of a renovation. We are happy to recommend tradesmen to assist with these, and they will be invoiced separately/directly if not originally quoted or specifically stated on quote).